#8 light Feeder wheel loose
Posted by corndog1 - 03 Feb 2013 14:18

#8 light and I also found that My feeder wheel is loose allowing the corn to go under it and not drop out of the Fill slots?? also still #8 light??. Can you direct me to how to remove the wheel? Possibly broken mount? Dunno thanks

==========

Re: #8 light Feeder wheel loose
Posted by Oldschool - 03 Feb 2013 17:19

Could be your mounting bolts are sheered off. I would remove the wheel it's self and then try to wiggle the motor shaft around to see if the bolts have broken. The Wiki has some good information on this.

==========

Re: #8 light Feeder wheel loose
Posted by corndog1 - 03 Feb 2013 18:36

Found the problem to be the four loose bolts under the feeder wheel, Cleaned the whole surfuce re-tightened the 5/32 bolts and replaced the feeder wheel.

No problem since. This is my stoves 9th season just prbobably wore loose . had that happen on the burn pot motor also two years ago. I'll do some Preventative Maintenace in spring.

==========

Re: #8 light Feeder wheel loose
Posted by Corny - 06 Feb 2013 12:34

Thanks cd. I added your adviceto the WIKI here: forum.iburncorn.com/wiki/index.php/Bixby...on_with_Error_Code_8 . Did I get it right?

If you're running the same stove for 9 years, you must be doing something right yourself.

==========